

MOUNTING POSITION - The DPR-22PS may be mounted in any position.

POWER INPUT - For a supply voltage of 120 VAC, connect the hot lead to the L1 terminal. For 208 to 277VAC, connect the hot lead to the L2 terminal. Connect the neutral lead to the **NEU** terminal. Connect the **GND** terminal to the electrical system ground.

METER CONNECTIONS - The DPR-22PS can be used with either a 2 wire or 3-wire metering system. The DPR-22PS's "K", "Y" and "Z" input terminals should be connected to the meter's "K", "Y" and "Z" terminals: "K" to "K", "Y" to "Y", and "Z" to "Z". (Z not used in 2-wire input format.) The DPR-22PS' "K" is common & provides the return from the meter's K terminal. The "Y" and "Z" inputs provide a "pulled-up" +13VDC to the meter's "Y" and "Z" terminals. Jumper J1 must be in the correct position for the input configuration format used.

FUSES - The fuses are 3AG or AGC type and may be up to <u>1/2 Amp</u> in size. Two 1/2 Amp fuses (F1 and F2) are supplied standard with the unit unless otherwise specified.

<u>OUTPUTS</u> - Two 3-wire isolated outputs are provided on the DPR-22PS. MOV transient suppression for the contacts of the solid state relays is provided internally.

DIVISION NUMBER SWITCHES - The division number switches, located between the input and output terminal blocks, should be set to the desired division number (ratio) between the input and output pulses. See the table (reverse side of this sheet) for dividing number switch settings from 1 to 255.

5

SOLID STATE INSTRUMENTS by Radian Research, Inc 3852 Fortune Dr, Lafayette, IN 47905

Phone: (765) 449-5576 Mail: technicalsupport@radianresearch.com