
INSTRUCTION SHEET RPR-3 PULSE ISOLATION RELAY





MOUNTING POSITION - Because the RPR-3 contains mercury-wetted relays, it must be mounted in a vertical position to operate correctly.

<u>INPUT</u> - The RPR-3 is powered by an AC or DC voltage of between 90 and 250 volts. Connect the L₁ voltage of the AC line (or DC's negative voltage) to the RPR-3's Kin terminal. Connect the L₂ voltage of the AC line (or the DC's positive voltage) to the Kout terminal on the meter. Connect the RPR-3's Yin terminal to the meter's Yout terminal. Connect the RPR-3's Zin terminal to the meter's Zout terminal. CUT jumper JP1 for 240V or 277V operation. (See note above.) No other power supply is required to use the RPR-3 relay.

FUSES - The output fuses are type 3AG and may be up to 1 Amp in size. Three 1/2 Amp fuses (F1, F2 & F3) are supplied standard with the unit unless otherwise specified.

<u>OUTPUTS</u> - Three 3-wire isolated outputs are provided on the RPR-3, with output terminals K1, Y1 & Z1; K2, Y2, & Z2; and K3, Y3 & Z3. Typical output circuit shown above. Arc suppression for the contacts of the mercury-wetted relays are provided internally.



SOLID STATE INSTRUMENTS

a division of Brayden Automation Corp. 6230 Aviation Circle, Loveland, Colorado 80538 Phone: (970)461-9600 Fax: (970)461-9605 E-mail:support@solidstateinstruments.com

Revision: 12/12/2005 P/N: 04003-97006B